

Zenith

## Fabre User Manual



- 1 Automatic Weight Adjustment**  
The reclining tension automatically adjusts to the user's weight.



- 2 Tension Lever**  
Switch the lever to adjust reclining tension strength (standard or firm). Also, lockable in the upright position.



- 3 Seat Height Adjustment**  
Operate the seat height lever to suit body height and seating posture.